



## Introducing Search


Search allows you to enter the name or partial name of a program or video you are looking for and have your service find any program matching the text you enter.

## Go To Search


Press **MENU** and highlight **Search**, then press **OK**.

## Search For A Program

### Step 1: Enter The Program Title



The highlight will be on the **Search** text box when the Search screen appears.



Press **OK** and a keyboard will appear to the right of the screen.

Highlight each letter in the name of the program you want to find, and press **OK** on each. Each time you press **OK** you will see that letter added to the text box.

If you enter a wrong letter, highlight **Del** and press **OK** to go back one space.

If you need to start over, highlight **Clear All** and press **OK**.


Once you have entered as much of the program name as you feel necessary, highlight **Done** and press **OK**.



# 12 Search


*Note: It is best to enter as little as possible when searching. Usually the first 3 or 4 letters in the name will be enough to find what you want.*

## Step 2: Search



Highlight **Search Guide** and press **OK** to have the system start searching for all programs that match your search criteria.

## Step 3: Pick A Result



You can now highlight any program or rental listing and press **OK** to...

Watch or record a program if it's on now.

Set a reminder, auto tune or recording for a program if it comes on later.

Add or remove the channel airing it to a favorites list.

You cannot set a reminder, auto tune or recording for Video on Demand rentals.